

TBL 5-3-5
Level Downlink Message Elements (LVLD)

CPDLC Message Sets			Operational Definition in PANS-ATM (Doc 4444)		
FANS 1/A	ATN B1	Response	Message Element Identifier	Message Element Intended Use	Format for Message Element Display
DM6 REQUEST <i>(altitude)</i> <i>Note – Used for a single level</i>	DM6 REQUEST <i>(level)</i>	Y	LVLD-1	Request to fly at the specified level or vertical range.	REQUEST <i>(level)</i>
DM9 REQUEST CLIMB TO <i>(altitude)</i>	DM9 REQUEST CLIMB TO <i>(level)</i>	Y	LVLD-2	Request for a climb to the specified level or vertical range.	REQUEST CLIMB TO <i>(level)</i>
DM10 REQUEST DESCENT TO <i>(altitude)</i>	DM10 REQUEST DESCENT TO <i>(level)</i>	Y	LVLD-3	Request for a descent to the specified level or vertical range.	REQUEST DESCENT TO <i>(level)</i>
DM38 ASSIGNED LEVEL <i>(altitude)</i> <i>Note – Used for a single level</i>	DM38 ASSIGNED LEVEL <i>(level)</i>	N	LVLD-11	Confirmation that the assigned level or vertical range is the specified level or vertical range.	ASSIGNED LEVEL <i>(level)</i>
DM61 DESCENDING TO <i>(altitude)</i> <i>Note – urgent alert attribute</i>	N/A	N	LVLD-14	Report indicating descending to the specified level.	DESCENDING TO <i>(level single)</i>