

TBL 5-3-17

## Free Text Downlink Message Elements (TXTD)

CPDLC Message Sets			Operational Definition in PANS-ATM (Doc 4444)		
FANS 1/A	ATN B1	Response	Message Element Identifier	Message Element Intended Use	Format for Message Element Display
DM68 ( <i>free text</i> ) <i>Note 1. – Urgency or Distress Alr (M)</i>  <i>Note 2. – Selecting any of the emergency message elements will result in this message element being enabled for the flight crew to include in the emergency message at their discretion.</i>	N/A	Y	TXTD-1		<i>(free text)</i> <i>Note – M alert attribute.</i>

TBL 5-3-18

## System Management Uplink Message Elements (SYSU)

CPDLC Message Sets			Operational Definition in PANS-ATM (Doc 4444)		
FANS 1/A	ATN B1	Response	Message Element Identifier	Message Element Intended Use	Format for Message Element Display
UM159 ERROR ( <i>error information</i> )	UM159 ERROR ( <i>error information</i> )	N	SYSU-1	System-generated notification of an error.	ERROR ( <i>error information</i> )
UM160 NEXT DATA AUTHORITY ( <i>ICAO facility designation</i> ) <i>Note – The facility designation is required.</i>	UM160 NEXT DATA AUTHORITY ( <i>facility</i> ) <i>Note – Facility parameter can specify a facility designation or no facility.</i>	N	SYSU-2	System-generated notification of the next data authority or the cancellation thereof.	NEXT DATA AUTHORITY ( <i>facility designation [O]</i> )